



**BEFORE USE
YOU MUST
UNSCREW ALL THE
PRE-INSTALLED FEET
AT LEAST 1/4"
IN ORDER FOR THE
SCALE TO WORK.**

**FEET ARE LOCATED ON EACH CORNER
ON THE UNDERSIDE OF THE SCALE.
PLEASE BE SURE THE FEET ARE EVENLY
SCREWED OUT AND THE SCALE IS LEVEL.**

